


Lighted Christmas Tree Assembly Instructions



1. Remove the stand from the plastic bag and pull the legs open, forming a "+".
2. Place the stand in the location where you want your tree to be displayed.
3. Remove the 2 green plastic pole protectors from the end of pole Sections A and B.
4. Remove all of the bubble wrap from the sections. Do not use a knife!
5. Place Section A into the stand, then insert and hand tighten the 3 bolts provided. (Section A is the brown trunk without branches.)
6. Place Section B into Section A.
7. Carefully cut or untie the red plastic cinch nearest the floor. The tree branches that were held by the cinch will fall into place.
8. Begin the shaping process, referring to the enclosed Tips for Shaping.
9. Cut the middle cinch, and shape the branches that are released.
10. Cut the top cinch, and shape the branches.
11. Locate the two piggybacked plugs in Section B, identified with a label marked "S".
12. Push the 2 piggybacked "S" plugs into the extension cord receptacle (also labeled with an "S") dangling from Section B.
13. Find the end of the extension cord under the tree. Remove it from the white box and plug in to your power supply. Section B of the tree will light up.
14. Insert the Tree Top into Section B.
15. Locate the plug attached to the Tree Top (also marked "S"), snake it down along the trunk of Section B, and push the plug firmly into the last plug piggybacked into receptacle "S". (There should now be 3 plugs piggybacked into receptacle "S".) The Tree Top will light up.
16. Take the extension cord receptacle and tuck it up into the bottom branches of Section B so it's hidden.
17. Cut the red cinches and shape the Tree Top. Don't forget to straighten the top of the tree so it's pointing upward.
18. Refer to the Centerpiece Garland Installation Suggestions on the back.

Contents:

- Stand
- 2 Pole Protectors
(for shipping only)
- Spare Light Bulbs are
located on every light set in the tree.

HAVE A MERRY CHRISTMAS!

For your safety, all decorative lighting should be turned off prior to going to bed or leaving your home

*Light sets are factory installed on each section

**Carefully read safety instructions included with light sets and extension cords

KL CP 3S 2008



One East Superior Suite 510
Chicago, IL 60611
Info@neumantree.com

Centerpiece Garland Installation Suggestions

Wrap the two tips from an end of the garland onto a leg (under the brace).



Gently pull the garland towards the leg to the right and wrap two tips under the brace of that leg.



Continue wrapping another two tips to the 3rd and 4th legs, always under the leg brace.



Finish decorating by wrapping the balance of the garland around the pole and then tuck the garland down to completely hide the stand.

Merry Christmas and thank you for buying a NeumanTree!

KL CP 3SB 2008