


# Lighted Christmas Tree Assembly Instructions



1. Remove the base from its box and carefully remove the protective bubble wrap.
2. Place the base in the location where you want your tree to be displayed.
3. Remove the green plastic pole protector from the end of pole Section A.
4. Remove all of the bubble wrap from Section A and the Tree Top. Do not use a knife!
5. Insert Section A into the base. Make sure it is in as far as it will go, gently turning Section A back and forth as necessary.
6. Carefully cut or untie the red plastic cinch nearest the floor. The tree branches that were held by the cinch will fall into place.
7. Begin the shaping process, referring to the enclosed Tips for Shaping.
8. Cut the middle cinch, and shape the branches that are released.
9. Cut the remaining cinch(es), and shape the branches.
10. Find the end of the extension cord under the tree. Remove it from the white box and plug in to your power supply. Section A of the tree will light up.
11. Insert the Tree Top into Section A.
12. Locate the plug attached to the Tree Top (marked "T") and push the plug firmly into receptacle T found at the top of Section A. The Tree Top will light up.
13. Don't forget to straighten the top of the tree so it's pointing upward.

## Contents:

- 1 Pole Protector (for shipping only)
- Spare Light Bulbs are located on every light set in the tree.

## HAVE A MERRY CHRISTMAS!

For your safety, all decorative lighting should be turned off prior to going to bed or leaving your home

\*Light sets are factory installed on each section

\*\*Carefully read safety instructions included with light sets and extension cords

KL FT 2S 2008



One East Superior Suite 510  
Chicago, IL 60611  
Info@neumantree.com