


Lighted Christmas Tree Assembly Instructions



1. Remove the stand from the plastic bag and pull the legs open, forming a “+”.
2. Place the stand in the location where you want your tree to be displayed. (For safety reasons, we urge you to avoid moving the tree once it is fully assembled.)
3. Remove the 2 green plastic pole protectors from the end of pole Sections A and B.
4. Remove all of the bubble wrap from the sections. **Do not use a knife!**
5. Place Bottom Section A into the stand, then insert and hand tighten the 3 bolts provided.
6. Carefully cut or untie the red plastic cinch nearest the floor. The tree branches that were held by the cinch will fall into place. (TIP: Don't cut the next cinch until this row has been shaped.)
7. Begin the shaping process, referring to the enclosed Tips for Shaping.
8. Cut the middle cinch, and repeat step 7. Do the same for the remaining cinch(es).
9. Insert Middle Section B into Bottom Section A.
10. Locate the plug and receptacle (each labeled with an “S”) near the point where Sections A and B are joined.
11. Push the plug firmly into the holes on the front of the receptacle. (Note: There is room for one plug only on the front of the receptacle; the back has room for two plugs, which are already in place. Do not remove them or attempt to push the plug into one of these.) (See Figure 1.)
12. Find the end of the extension cord under the tree. Remove it from the white box and plug in to your power supply.
13. Continue cutting the red cinches and shaping the branches of Section B, working from bottom to top of the section.
14. Insert the Tree Top into Section B.
15. Locate the plug and receptacle (each labeled with a “T”) near the point where the Tree Top and Section B are joined. (See Figure 2.)
16. Push the plug firmly into the receptacle.
17. Cut the red cinches and shape the Tree Top.
18. Don't forget to straighten the top of the tree so it's pointing upward.

Contents:

- Stand
- 2 Pole Protectors
(for shipping only)
- Spare Light Bulbs are
located on every light set in the tree.

HAVE A MERRY CHRISTMAS!

For your safety, all decorative lighting should be turned off
prior to going to bed or leaving your home

*Light sets are factory installed on each section

**Carefully read safety instructions included with light sets and extension cords

KL 6.5, 7.5' 3S 2008



One East Superior Suite 510
Chicago, IL 60611
Info@neumantree.com